
26
28
EV
14
GPS
16
12
Data-coded
Instruction
Motorist
Radio/
Receiver
EVI
Slave Controller
OBD Computer
(Motorist)
Emergency
Vehicle Data
10
EVI Primary
Frequency (Audio)
EVI Sub-Carrier
Frequency (Data)
22
GPS
18
24
EVI
Transmitter
EVI
Master Controller
OBD Computer
(Emergency
Vehicle)
20

FIG. 1



FIG 2



FIG. 3